

Things you may like to know about:

Miracle Wash Laundry Balls

Why use the Miracle Wash Laundry Balls?

Beside the fact that they are environmentally safe, they are also safe for those with chemical sensitivity, babies and sensitive skin. They will also save you water and money.

What makes the Miracle Wash Laundry Ball environmentally safe?

The pellets in the balls are made from inorganic minerals with a very mild biodegradable surfactant to help the cleaning process. The minerals alter the water molecules which soften the fabric and open the weave (thus removing the need for use of fabric softeners). The movement of the water removes the dirt from the fabric.

Water from the wash can be reused on the garden and tests show they will not alter the delicate soil structure.

If you have a Top Loader machine, you can turn your rinse cycle off – a washing machine uses a rinse cycle to remove residue left over from laundry powders and detergents. The Miracle Wash Laundry Balls do not leave a residue on the clothes, so they don't need to be rinsed, saving you time and precious water.

The Miracle Wash Laundry Ball does not contain Sodium Lauryl Sulphate (which is an eye and skin irritant) and is **the only mineral pellet laundry ball in the world that is SLS free.**

Can I use them in my washing machine?

Miracle Wash Laundry Balls can be used in:

- Front Loaders
- Top Loaders
- Twin Tubs
- and even for Hand Washing

How do I use them?

You simply throw two balls in your washing machine and they will replace all your washing detergents and fabric softeners.

We recommend you use:

Two balls for a 3-7kg machine

Three balls for an 8kg+ machine

You can even use 4 balls if you have a really big machine and a big family.

Once you remove your washing from the machine, place the balls on a window sill or similar to help them dry out, the pellets will last longer this way.

How long will the pellets last?

As a general rule, the pellets last up to 6 months (this depends on how many times you wash and also on the water you use), longer if you use cold water and turn your rinse cycle off.

It is time to refill when you notice that the washing 'power' diminishes. The top-up refills that come with the starter kit will not fill a whole ball but the packs of refills, sold separately, will fill 2 balls.

Families: the balls usually last around 4-5 months

A Couple: around 6-8 months

A Single: 12 months or more

There is no need to buy the balls again, you can just purchase the refills and keep refilling the balls. Once you're on refills you will only spend about 12c per wash, the most common laundry detergents in supermarkets range from 15c-80c per wash. By using the Miracle Wash Laundry Balls you also eliminate the need for fabric softeners.

What won't the Miracle Wash Laundry Balls do?

They will NOT remove grease or oil as the pellets do not contain any bleach, optimizers, builders or fillers nor do they contain enzymes that break down the protein in grease.

To tackle stains:

A small tube of stain remover is provided in the starter kit. You can also buy this product separately in a larger tube. Use the stain remover directly on the stain as a paste, rub under some water or mix it up into a spray bottle. When making stain remover spray, use a 500ml spray bottle of water and squeeze 10cm of the paste into it, shake well and leave overnight

Use a pre-treatment on all heavy stains.

If you are an ex-Omo user (or similar) you can use ½ cup of Bicarb Soda with your whites to keep them bright.

Happy Washing Days!